

INSTALLATION



The equipment is easy to install! All equipment has cables and fixings! You can do it yourself. As you can see in the picture, antenna installed on the wall of the entrance /exit fitness club. The antennas are connected to the reader and the computer using the cable LAN with RJ45. In all industrial tablets the Anti-Theft software is installed and configured - it's completely ready to work. Alternatively, the software is installed and configured on your computers **remotely** (TeamViewer). When somebody try to steal towels, on the computer you can hear beep and see the information about what kind of textile try to steal and what kind of exit/entrance.